



## INSTALLATION AND OWNER'S MANUAL

Z2452 and Z2453 VStream Replacement  
Windscreen for K 1200 GT  
Quantum Coated Lexan® Polycarbonate

### Attention




Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

### Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



**TOOLS REQUIRED:**  
Torx Wrench, T25



Right and left side of motorcycle is determined while sitting on the bike.

### PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	VStream Windshield, Quantum Coated Lexan® Polycarbonate	1

### INSTALLATION



**Retain all fasteners, as they will be reused.**

1. Remove the 6 screws holding the outside plates on stock windshield. **(Torx Wrench, T25)**
2. Remove stock windscreen.
3. Reinstall the stock outside plates onto your new VStream windshield using stock screws. **(Torx Wrench, T25)**
4. Tighten the bolts firmly. **(Torx Wrench, T25)**

### MAINTENANCE

**Cleaning:** Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

View ZTechnik® K 1200 GT products at  
[www.ZTechnik.com](http://www.ZTechnik.com)

CARBON FIBER • EXHAUST SYSTEMS • STORAGE POD  
TECHMOUNT MOUNTS